
#### Step 1

#### Set up the T watch part

Instill the DHT senor library



Set up the IP address and connect the T watch to the WIFI with Arduino.

#### Step 2

## Update Github stuff on the sever to the latest version git pull

#### Step 3

#### Keep the server running all the time

```
sudo npm install -g n forever

sudo n latest

forever start server.js
ubuntu@ip-172-31-47-197:~/AME394Fall2019/cloudLogDHT11$ forever start server.js
warn: --minUptime not set. Defaulting to: 1000ms
warn: --spinSleepTime not set. Your script will exit if it does not stay up f
or at least 1000ms
info: Forever processing file: server.js
ubuntu@ip-172-31-47-197:~/AME394Fall2019/cloudLogDHT11$
```

# Step 4 Set up MongoDb on Ubuntu

```
sudo apt update
sudo apt install nodejs npm mongodb-clients mongodb-server
sudo npm install -g n forever
sudo n latest
```

restart the MongoDb

sudo service mongodb restart

### Step 5

Get the latest date (temperature from the data base)

db.users.find({}).sort({\_id:-1}.limit(1)